




AXIS TP3205




Installation guide
Guide d'installation
Installationsanleitung
Guida all'installazione
Guía de instalación
インストールガイド
Guia de instalação
Руководство по установке
설치가이드
安裝指南
Panduan instalasi




1x



1x



1x




1x




4x


i



i



1.1




1:1




[axis.com/products/
axis-tp3205/support](https://axis.com/products/axis-tp3205/support)




Drill template







1.2





1.3




1.4




i




$\geq 10 \text{ mm}$
($\geq 0.4 \text{ in}$)




1.5




1.6



1.7




1.8



2.1



4x  TR20




Installation guide




2x





2.2



2.3



2.4





3126187

2025-01 (M1.3)

© 2025 Axis Communications AB